


# Sådan får du mail og Push ved alarm

log ind med dit BrugerId og dit password



The image shows a screenshot of the Y-cam website's login and sign-up interface. At the top, the Y-cam logo is displayed. Below it, the heading "Log in to your Y-cam account" is centered. There are two input fields: the first is labeled "DitBrugerID" and the second is a password field with seven dots. Below the password field is a checkbox labeled "Keep me logged in". A blue "Login" button is positioned below the checkbox. Underneath the button is a link that says "Forgotten your password?". Below this section, the heading "Create a Y-cam account" is centered, followed by a grey "Sign Up" button. At the bottom of this section is a link that says "Learn more about Y-cam".

# Sådan får du mail og Push ved alarm

Vælg "Camera Settings"

The screenshot shows the Y-CAM web interface. At the top right, it says "Logged in as: alarm1@joergenjunge.dk Log Out". The navigation menu includes "My Home", "Watch Live", "My Videos", "Camera Settings", "Support", and "My Account". A large banner for "Y-CAM Introducing the new and improved Y-cam Plus Service!" features a hand holding a box with a plus sign and floating icons. Below the banner is the "My cameras" section for camera ID "08a00101", which includes a live video feed and four control icons: Connection, Motion Recording, Alert Notification, and Settings.

Y-CAM<sup>®</sup> My Home Watch Live My Videos Camera Settings Support My Account

Logged in as: alarm1@joergenjunge.dk Log Out

Y-CAM<sup>®</sup>  
Introducing the new and improved  
Y-cam **Plus Service!**

My cameras ⓘ ▶

08a00101





Connection Motion Recording Alert Notification Settings

# Sådan får du mail og Push ved alarm

Vælg ”tandhjulet – Camera settings”

Y-CAM My Home Watch Live My Videos **Camera Settings** Support My Account

Logged in as: alarm1@joergenjunge.dk [Log Out](#)

Camera name	Recording plan	Camera info	Camera settings	Motion recording settings	Wi-Fi settings	De-activate
08a00101	Free	ID: 8CAE89050F34 Added on: 14th Oct 2016				


[Add new camera](#) [Buy a new camera](#)

© 2016 Y-cam Solutions Ltd. All rights reserved. [Terms of Service](#). Ver. 2.1.11

Y-CAM

# Sådan får du mail og Push ved alarm

Klik på "Both" under Alert Notification Settings.



Y-CAM My Home Watch Live My Videos Camera Settings Support My Account Logged in as: alarm1@joergenjunge.dk Log Out

### Camera Settings

Camera Name:

Camera ID:

Camera microphone:  Enable  Disable  
If you do not want audio on live view and recordings you can disable the microphone

Online/Offline notifications:  Enable  Disable  
This setting is only for camera Offline/Online notifications and will not affect setting for Motion Alert notifications.

Night Vision:  Enable  Disable  Auto  
This setting is to enable, disable or automate your Night Vision settings

Image with E-mail attachment:  Enable  Disable  
If you do not want the latest image attached to your e-mail notification, you can disable it here

Alert Notification Settings:  E-mail  Push Notification  Both  
This settings will choose where your alert notification will be sent to

Video Stream Settings:  High quality  Standard quality  
This controls the video quality when watching Live View and Video Archive clips.

© 2016 Y-cam Solutions Ltd. All rights reserved. [Terms of Service](#). Ver. 2.1.11

Y-CAM